

Suntree

Technologies Inc.

798 Clearlake Road, Suite 2, Cocoa, FL 32922

Tel: 321-637-7552 Fax: 321-637-7554

www.suntreetech.com

Curb Inlet Basket

(PATENTED)

Maintenance Procedures

Description

The recommended service interval for the Curb Inlet Basket is quarterly. Service interval can be affected by site conditions so that it may be that the interval is longer or shorter than the quarterly recommendation. The maximum flow capacity of the *Curb Inlet Basket* will be restored after each servicing. Because all the screens are made from stainless steel, after each servicing the flow rate through the unit will be the same as a brand new unit no matter if it is serviced 10 times or 100 times. There are 2 primary methods of servicing which are described below.

Manual Servicing

1. Remove the manhole cover and place off to the side on the ground.
2. Remove the Curb Basket from the catch basin.
3. Cut zip ties and remove the Storm Boom from the basket.
4. Dump contents of basket into trash container, and brush screens clean.
5. Attach new Storm Boom to basket with zip ties provided.
6. Replace Curb Inlet Basket into the inlet.
7. Replace manhole cover back onto grate frame.

Vacuum Servicing

1. Follow above procedures except that Curb Inlet Basket can be left in place and vacuumed out If not replacing the Storm Boom. Brush screens and vacuum remaining residue.